




# Bottled Water Pump

Model 900179H

Primo Water Corporation  
101 N. Cherry St. Suite 501  
Winston-Salem, NC 27101

PN O-030 D © 2016



## Prepare Bottle

If your bottle has threads, screw adapter onto bottle.

If your bottle does NOT have threads, remove the cap and label from top of bottle.

## Assemble Pump

1. Assemble tubes by connecting sections to desired length.
2. Attach assembled tubes to bottom of pump.
3. Attach spout to pump.
4. Insert assembled pump into bottle.
5. Turn collar to secure pump to bottle.

## Use

1. Place cup, glass or pitcher under spout.
2. Press down on top of pump several times to make water flow.

## Cleaning and Care

1. Clean pump with a cloth, mild dishwashing soap and water.
2. Clean tubes and spout in dishwasher.
3. Store disassembled in a clean, dry location.

## Questions

For expert advice, call us toll free at **866-429-7566** or visit [www.PrimoWater.com](http://www.PrimoWater.com) for additional information.

